

## Included Components:

- 1x Slim-Grip® Ultra Pro Tablet Holder with Support Legs (SP20MM1420)
- 1x Drill-Base Mount with 22mm Arm (HD003NHB)

### Hardware Specifications

4x	Philips drill M4 Coarse 22mm
4x	Philips drill M4 Coarse 26mm
4x	Drill Wall Anchor M4 26mm


**Important:** Clean the application surface and make sure it is free of dirt, dust, and grease before installation.

### Camera Adapter

**Compatibility:** Any device that utilizes a 1/4"-20 mounting adapter.


## 1 Secure the Base

For easier installation, remove the base from the pedestal if needed. Align the base with your mounting surface and tighten the four screws. Use the included anchors for drywall or similar materials.




## 2 Attach Camera Adapter

Loosen the knob by turning it counterclockwise, insert the 20mm ball adapter, then tighten to secure it to the mounting pedestal.




## 3 Adjust the Mount

Loosen the knobs to reposition the mount, then retighten to lock it in place.



## 4 Mounting Your Camera on the Holder

Attach your camera on to the mounting pedestal by inserting and twisting it clockwise to secure the position.



### WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

### WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

