




Packaging Contents

A. LockVise™ Locking Holder [TAB005KL]

- Foam pads (x2)
- Locking keys set
- 8-32 UNC screws (x4), 3/32 allen key socket

B. Metal AMPS Pattern to 38mm Ball [APMAMPS38MM]

C. 5.75-inch Double Socket Shaft [SPRM3850]


D. Clamp Base to 38mm Ball [CPM38]

Please note that screws are not included.

Important: Clean the surface of dirt, dust, and grease before installation.


Attach the Ball Adapter to the Tablet Holder

Align the ball adapter plate with the mounting holes on the back of the tablet holder, then secure it with the screws included.




Assemble the Mount

Turn the shaft knob counterclockwise to loosen it. Insert the ball ends of the base and adapter plate into each end of the shaft, then turn clockwise to tighten and secure both ball joints in place.




Install the Clamp

Turn the knob counterclockwise to open the clamp. Position the clamp on the mounting surface, then turn the knob clockwise until securely tightened.



Adjust the Tablet Holder

Use a Phillips screwdriver to loosen the adjustment screws. Adjust the holder's width and depth to fit your tablet, then retighten the screws to secure the holder in place.



WARNING
CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system.

WARNING
Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

