




Includes:

- 1 - Slim-Grip® Ultra Pro Tablet Holder with Support Legs (TAB006AMPSXL)
- 1 - Drill Base Mount with 3.75" Shaft Arm (RM2XAMPS-MET)

Please note the contents included:

- 4 - M4 x 12mm Screws
- 5 - Support legs (SPTAB6FT)

Important: Clean the application surface and make sure it is free of dirt, dust, and grease before installation.

Leg Selection Guide


Choose the appropriate legs based on your tablet size, with or without a case:

- Tablets (approximately 6.37" to 8.81") - Use 2 small legs.
- Tablets (approximately 7.12" to 9.25") - Use 1 long leg and 1 small leg.
- Tablets (approximately 7.62" to 10") - Use 2 long legs.
- Tablets (approximately 8.75" to 11.12") - Use 1 long leg and 1 extra long leg.

1

Disassemble the AMPS adapter plate from the pedestal


To detach one of the AMPS adapters from the drill base pedestal, simply turn the shaft knob counterclockwise.



2

Install the AMPS adapter plate to the holder


Align the AMPS 4-hole adapter on the back of the holder. Then, insert the four mounting screws through the AMPS 4-hole ball adapter plate and into the holder. Finally, secure the screws tightly.



3

Mount Installation


To secure the pedestal to the mounting surface, align the screws (**not included**) with the AMPS adapter. If necessary, detach the shaft from the adapter to streamline the installation process.



4

Assemble the components

Locate the shaft arm and turn to the adjustment knob counterclockwise to expand. Insert the 25mm ball ends into the shaft. Turn clockwise to tighten.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.


Continued on page 2



5

Installing the legs to the holder


Install the support legs required based on the recommendations listed above. Slide the support legs into the holder's support leg channels.



6

Extend the spring-loaded mechanism

To extend the legs, insert one end of the tablet into the bottom support legs.



7

Install the tablet


With the holder's spring-loaded support legs expanded, lay the tablet flat on the holder.



8

Release the tablet to secure

Gently release the tablet into the holder, allowing the bottom spring-loaded support legs to secure the tablet.



WARNING

CHOKING HAZARD - Keep out of reach from children under 8 yrs. as they can choke or suffocate on parts included with this system

WARNING

Arkon® is not responsible for any damages caused to your device or yourself due to the installation or use of this mount. Do not install Arkon® products near areas that interfere with operation of vehicles. Arkon® assumes no responsibility or liability for injury or death as a result of failure to install in a safe location. Arkon® is not responsible for any damages caused to vehicles, product, or people due to the installation or use of this product.

